


Key Mapper



USER'S MANUAL

www.onerugged.con



Button Assignment Overview

1. Interface Description

1.1 How to add key mapping.....01



Key Mapper


Button Assignment Overview

Function: Button Assignment helps administrators to customize the functions or services triggered by device buttons, making it easier and more effective to use.

Application: Through Button Assignment, you can select the button you want to set and give the function or service that the button can wake up by operation, helping subsequent users to complete their work tasks more easily and quickly.

1. Interface Description

When you open the "Button Assignment" app, you will see the following interface.



1. Click "ADD KEY MAPPING" to enter the custom add interface, where you can define the functions or services that each key can wake up according to your needs (see 2. How to add key mapping instructions for details);

2. Box 2 shows the contents of the added key mapping, and you can delete the set



keys according to your needs; click " " to control whether the setting is
applied or not;

Click the "Three dots icon" on the top right of the left figure to open the right interface.

3. Click "Import configuration data" to import customized keystrokes in batch in the form of File/Scan;

4. Click "Export configuration data" to export the defined key settings in File/QRCode format;

5. Click "About" to check the APP Version and check for updates.




1.1 How to add key mapping

INERugged

1. click "ADD KEY MAPPING", enter the following interface, then press the key you want to set, the key will be displayed in the "keycode" column, for example: you want to set click the "volume +" button to open the screenshot function, then you need to press the "volume +" button, so that it appears in the "keycode" column, as shown in the following figure.





2. After adding "keycode", click on "SingleClick (down)", "SingleClick (up)", "DoubleClick", "LongClick" below to set the state in which the key will achieve the subsequent custom function (Note: "SingleClick (down)", "SingleClick (up)" and "DoubleClick", "LongClick" cannot be set at the same time).

3. After confirming the key mapping start status, the following interface will pop up, in which you can set the

"Operation"/"Application"/"Shortcut"/"SendBroadcast" that the key can wake up (the specific content of "SendBroadcast" can be set through the "Broadcast Mapping List" App).



INERUgged Your One-Stop Rugged Computing Solution Provider

Key Mapper




Image: New Your One-Stop Rugged Computing Solution Provider

Key Mapper